Gasboy Dial Credit and Debit Card Networks

Version 001

for Site Controller II versions 2.3 and above

for CFN III versions 3.3 and above

part number: C35930

Gasboy International LLC

Gasboy CFN Series

Gasboy Dial 001 Credit and Debit Card Networks

Site Controller II version 2.3 and above

CFN III version 3.3 and above

03/07/03

C35930

Gasboy International LLC Lansdale, Pennsylvania

Gasboy International LLC P. O. Box 309 Lansdale, PA 19446

Copyright 2003 by Gasboy International LLC All rights reserved. Printed in the United States of America.

The information in this document is confidential and proprietary. No further disclosure thereof shall be made without permission from Gasboy International LLC.

Gasboy International LLC believes that the information in this document is accurate and reliable. However, we assume no responsibility for its use, nor for any infringements of patents or other rights of third parties resulting from its use. We reserve the right to make changes at any time without notice.

	REVISION RECORD O	F THIS DOCUMENT
Part No.	Date Published	Site Controller Release Levels
C35930	April 12, 2001	SC II Version 2.3 and above CFN III Version 3.3 and above
C35930	November 14, 2002	SC II Version 2.3 and above CFN III Version 3.3 and above
C35930	March 7, 2003	SC II Version 2.3 and above CFN III Version 3.3 and above

Site Controller II Related Publications

Site Controller - versions 2.3 and 3.3 and above

Part No.	Title
C09212	SC II Manager's Manual, version 2.3
C01918	SC II Installation Manual, version 2.3
C09213	SC II Configuration Manual, version 2.3
C09159	SC II Pocket Reference, version 2.3
C35920	CFN3 Manager's Manual for Windows NT, version 3.3
C09326	CFN3 Configuration Manual for Windows NT, version 3.3
C35921	CFN3 Pocket Reference
C09204	Check Point Reference Manual
C35745	Profit Point Clerk's Manual
C35746	Profit Point Reference Manual
C35923	Point of Sale and Shift Change, version 003

Credit and Debit Card Networks

C35931	Amoco/DataCard	C35907	Gascard
C35901	Buypass	C35909	Generic Dial
C35914	ADS-Chicago (formerly SPS/Phillips)	C35908	PaymenTech (formerly Gensar)
C35902	ADS-CITGO	C35910	NaBANCO
C35906	ADS-FINA	C35911	NDC
C35919	ADS-ZION	C35913	Sinclair
C35904	EDS-CCIS	C35915	T-Chek
C35903	Comdata	C35916	UFDA
C35905	FDR	C35917	VDOT
C35930	Gasboy Dial	C35918	VisaNet

Pump Interface

C09146	Pump Interface Manual
C01745	Gilbarco Interface Unit
C35849	SDI/Wayne CAT Interface
C35924	SDI/Unitec Interface

C35933 Insight Interface

Card Encoding and Miscellaneous

- C09136 CFN Series Clubcard Format
- C01687 CFN Series Card Encoding Manual

Remote Communications

C09141 PC/SiteControl User's Manual

Technical Publications

C01759 CFN Diagnostic Manual

Table of Contents

Cards accepted
Preparing for configuration
Setting up your Site
Miscellaneous Setup Notes
Running GASDIAL
Read/Write a Network File (-R, -W)
Initialize Current Gasboy Dial Configuration (-I)
Edit Network Parameters (-E)
Edit Card Parameters (-C)
Program New Cards for Acceptance (-O)7
Edit Modem Parameters
Edit Instant-On for Pumps (-P) (not available) 10
Edit Product Cross References (-X)
Print Current Gasboy Dial System Configuration (-S)
Start Attended/Unattended Service (-G)
Remove Transactions from Batch (-D)
Read/Write Network Parameters from/to file (-R/-W)
Detailed notes on system setup
Tables (TABLE)
Transaction format (TRFMT)
System Date
Disabling Cards at the Island during the evening
System Parameters (SYS_PAR) 17
Console (CONSOLE)
Reader (READER)
Settlement for Gasboy Dial
Error messages
Special console operations
Special credit card keys for manual entry
The transaction pointer
Troubleshooting

001Gasboy Dial

The Gasboy Dial network, revision 001, will work only with the 2.3 or higher version of the Site Controller II and version 3.3 or higher of the CFN III. This manual refers to software version 001 or greater. If you are connecting your site to the following Network Hosts for card verification, use this manual for reference.

Some functions of this program are not available but have been included in this software and manual release for reference only.

Specifically:

- 1. Instant-On does not function at this time. Please ignore any reference to Instant-On in the software menus and in this manual.
- 2. Debit Cards are not accepted.
- 3. Only specific credit cards and fleet cards are available. These are listed.

Cards accepted

The Gasboy Dial network currently accepts these credit cards:

AMEX	MasterCard
Discover	VISA

Fleet cards supported by the network interface:

Fleet 1	PH & H
Gasboy Club Card	Visa Fleet
Growmark Fuel24	Voyager
MasterCard Fleet	WEX

Special cards supported by the network interface:

Quarles

Contact your Gasboy Sales Representative for updates.

In addition, new cards can be set up to be accepted by modifying a network card table. Contact your bank representative for card information.

The Gasboy Dial software allows the VISA/MasterCard restriction on the credit card account number printed on Island receipts to be set by running **GASDIAL** -C. Only 4 digits will be printed instead of the complete number. All cards can be programmed to display all, none, comply with the VISA/MasterCard restriction, or the domestic PH&H format (suppresses the first 4 and last digits).

Note: If this is an NBS-Growmark configuration, the club card is called Fuel24, for a NBS configuration, the club card is called Gasboy Club.

Bank Card transactions will obey the \$50 Pay-at-the-Pump limit unless overridden by the customer. **Note**: You must have permission from your network representative before setting the limit above \$50.

Preparing for configuration

There are two basic configurations: Generic and NBS. Determine which one you will use before beginning the configuration.

Before you configure, get the following information from your network representative:

- Your terminal type (GASBOY is the default).
- Your Merchant ID.
- For NBS bank hosts, the terminal type must not be sent (see Network Parameters)
- Determine if DEBIT cards are to be accepted. (Not available)
- The phone number the modem dials to receive authorizations.
- The baud rate for the modem communications.

You will need a modem for connection to the Gasboy Dial network. This is in addition to a dial-in (remote login) modem.

Determine the Site Controller port to be assigned to connect to the Gasboy Dial host, and connect that port to a Hayes Compatible 1200 or 2400 baud modem or one that is 100% compatible. (See the Hayes dial-out settings in the *Site Controller II or CNF3 Manager's Manual, Modem* appendix)

Setting up your Site

WARNING!!! Before initializing Gasboy Dial, all previous transactions for any existing network interface must be settled. Failure to do so may cause loss of transaction data.

Make sure your router table has at least 1808 (must be even number) entries. (You can check these settings - and make changes, if necessary - at the prompt by running **TABLE**.) If you change the size of the router table, reboot the Site Controller after you exit from the table program.

The operating system will warn you if not enough space is available for the router table. If that happens, make the transaction table smaller to make room for more router table space.

Run **GASDIAL -I** to reset all router values to defaults by erasing whatever changes you have entered. The network data tables affected are the card parameters, instant-on pump tables and product cross reference. They will need to be re-entered.

To initialize:

- 1. Run FIX TRANS;I.
- 2. Run TABLE, make sure the router table size is at least 1808.
- 3. Reboot.
- Run GASDIAL -I to initialize the network parameters. At the prompt select 1-Generic, 2-NBS, or 3-NBS-Growmark.
- 5. Run GASDIAL -E (or from the menu system, select Edit Network Parameters).
- 6. Select the main menu option, W. This will step you through all of the basic data needed for the network.
- For Dial-out, run MODEMS to set up the modem type, baud and port. The setup only needs to be done once. The parameters are stored in the modem's non-volatile memory. This program only needs to be run again if you change modems used for dial-out.
- 8. Reboot.
- 9. Run GASDIAL -C to set the card parameters.
- 10. If using special programmed cards, run GASDIAL -O.
- 11. Run GASDIAL -X to set the product cross references.

Miscellaneous Setup Notes

In the Growmark configuration, post-pay transactions are sent as a pre-authorization/completion pair.

Running GASDIAL

The GASDIAL command will prompt you for each item of needed information. The program also checks data and warns you when errors occur and lists how they might be fixed.

The program can be run in two ways:

- menu
- command line.

Menu

GASBOY Dial Main Menu
1. Initialize Network Parameters
2. Edit Network Parameters
3. Edit Card Parameters
4. Edit Programmable Card Parameters
5. Edit Modem Parameters
6. Edit Instant On for Pumps (N/A)
7. Edit Product Cross References
8. Print System Configuration
9. Start Attended/Unattended Service
10. Remove Transactions from Batch
11. Read Network Parameters from File
12. Write Network Parameters to File
Output To : Screen
Enter Menu Number, F-File, S-Screen, ?-Help, Q-Quit :

To run *GASDIAL* in menu mode, type *GASDIAL* and the following main menu will appear.

Enter the number to the left of an item to execute that item. Enter '?' to print the options for the command line execution of the program.

Command Line

The command line format of the program is:

GASDIAL [options]

where the valid options are:

-I	Initialize Network Parameters
-E	Edit Network Parameters
-C	Edit Card Parameters
-0	Edit Programmable Card Parameters
- M	Edit Modem Parameters (MODEMS command calls same screen)
-P	Edit Instant On for Pumps (not available)
-X	Edit Product Cross References
-S	Print System Configuration
-G <0 1>	Start Attended (0)/Unattended (1) Service
-D <trans#></trans#>	Remove Transactions from Batch (<first> <optional last="">)</optional></first>
-R <file></file>	Read Network Parameters from File
-W < <i>file</i> >	Write Network Parameters to File
-?	Displays command line options.

Saving Parameter Changes

To save any changes you make with the Gasboy Dial options, select Quit and answer *Yes* to the save changes prompt. The program stores the information in FRAMOS.CFG and/or in the router tables. *If you do not answer* Yes, *none of the information you have entered will be saved!* Reboot the program to load the new configuration.

The program then runs a check on all the Gasboy Dial-related parameters. Some parameters cannot be edited within this program, but the appropriate program is mentioned if a problem occurs. A message will be displayed that tells you which of the parameters is in error. There is no message displayed unless there is an error.

Read/Write a Network File (-R, -W)

Network information and card parameters can be saved to a file. You can then use the file to reload this configuration if data is ever lost.

To save the data to a file, enter the command **GASDIAL** -W *filename*. Then copy the new file and your FRAMOS.CFG file to a diskette for safe-keeping. To load or restore the data, enter **GASDIAL** -R *filename*. You can also use the menu options 11 and 12 as illustrated on page 16.


Initialize Current Gasboy Dial Configuration (-I)

This screen initializes the default router values and will request a configuration type. Contact your Network Representative for the correct selection among, Generic, NBS, NBS-Growmark.

NBS has a different format for the data. If you connect to NBS but get errors on all transactions, check this field.

GROWMARK requires a transaction # on all post-pay sales. The site is not equipped to provide a transaction # until authorization so all post-pay sales are sent as a pre-auth/completion pair.

Note: Do not use this command unless you want to reset all of the router values back to their default settings. This option resets all router values to defaults by erasing whatever changes you have entered. The network data tables affected are the card parameters, the instant-on pump tables, and the product cross reference tables. They will need to be re-entered.



Edit Network Parameters (-E)

Edit Network Parameters using the edit screens. Sample screen is displayed showing the NBS Growmark Fleet Parameters as an example:

Copyright (2001) Gasboy International
Network Setup for CFN/3
Gasboy (001)
EDIT NBS GROWMARK FLEET PARAMETERS
1. Main Bank Phone Number : 9,16121234565
2. Backup Bank Phone Number : 9,16121234565
3. Carrier Wait Timeout : 20
4. Verification Timeout : 45
5. Terminal Type :
6. Merchant ID : GB1012345678991
7. Send Fleet Format to Host : Enabled
8. Debit : Disabled
9. Send Term Type to Host : NBS format
10. Instant On : Disabled
11. Instant On Timeout : 0
12. Fallback Sequence : 1
Enter Item Number, W-Walkthrough, ?-Help, Q-Quit :

To edit a parameter, enter its menu number. The W option steps you through each parameter in the program. To get help, enter a '?'.

For Debit cards to be accepted, the Debit parameter must be enabled, (not available).

For NBS, the Terminal Type must be suppressed. Answer "No" to the "Send term type to host".

Instant On (Not Available)

Instant On allows the pump to be turned on before the purchase authorization is received. You can disable Instant On by setting item 10 to *Disabled* or by setting the timeout (item 11) to 0.

Under instant-on the card is preliminary approved immediately and the network is subsequently dialed. If the card is found to be bad, the transaction is halted. A second insertion of the card would not be approved until the network has been dialed and approval received.

Note: With instant-on, the merchant accepts responsibility on denied transactions, which are listed as unpaid.

Edit Card Parameters (-C)


These screens set the purchase limits of the various cards. The Purch limit is used to set the maximum amount for purchase.

Se	elect option	on 3	from t	he menu	or type	GASDIAL	-C to dis	play tl	he fol	lowing screen:	

	Сору	rig	ght (20 Networ			-				nal		
			G	asl	boy(C	01)					
			EDIT	C	ARD F	PAR	AMETE	RS				
												N/A
CARD	SYM	OK	Okay	P١	urch	Is	sle	Is	sle	Rcpt	Price	Inst
			Flags	L	imit	A۱	uth	Ma	ax	Acct	Level	On
1. VISA		Y	EFRUV				1			4	Credit	N
MasterCard	MC	Y	EFRUV				1				Credit	N
3. Discover	DS	Y	EFRUV	\$	999	\$	1	\$	50	4	Credit	N
4. AMEX	AX	Y	EFRUV	\$	999	\$	1	\$	50	4	Credit	N
5. Gasboy Club	CLUB	Y	RUV	\$	999	\$	250	\$	250	A	3	N
6. WEX	WX	Y	E RUV	\$	999	\$	250	\$	250	A	Credit	N
7. PHH	PH	Y	E RUV	\$	999	\$	250	\$	250	S	Credit	N
8. Voyager	VY	Y	E RUV	\$	999	\$	250	\$	250	A	Credit	N
9. Fleet One	F1	Y	RUV	\$	999	\$	250	\$	250	A	Credit	N
10. Visa Fleet	VSF	Y	E RUV	\$	999	\$	250	\$	250	A	Credit	N
Enter Item Number,	W-Walł	cthi	rough,	RE'	rurn-	Nez	xt Pa	ge	,			
?-Help, Q-Quit :												

	CARD	SYM	-	Purch Limit			~	Price Level	N/A Inst On	second page
11.	MC Fleet	MCF	Y E RUV	Ş 999	Ş 250	\$ 250	A	Credit	N	
12.	Quarles	QU	Y E RUV	\$ 999	\$ 250	\$ 250	A	Credit	N	

Select a card to edit by entering the corresponding number. In the following example the Item number 1 was entered:



Items entered in this table are at the discretion of the customer. Gasboy assumes no responsibility for any incorrect information entered here.

For Island Card Reader (ICR) sales, the *Island Preauth* field is used to set the amount requested from the host. For Bank Cards, this should be set to \$1 to comply with PS2000 Pay-at-the-pump standards. Transactions preauthorized with \$1 preauth amounts will only be allowed to pump \$50 maximum.

The Card Number on ICR Receipt option allows four values:

- 'A' All digits printed.
- '4' Last four digits only.
- 'S' Suppress first four digits and last (check) digit. This is for use by domestic PH&H cards.
- 'N' None, no digit shown.

If the account number will be printed on the customer receipt when the purchase is done at an island card reader (check with your bank to see if they allow this), then set the value to '**A**' for all digits to be printed. VISA and MasterCard restrict bank card account numbers printed on the Island receipt to the last four digits of the account number. You can set this restriction by entering a '**2**' at this prompt.

The *Fuel Override Price Level* field is used to set a special price level for a card: 1 is cash, 2 is credit. The normal stand-in level is 0 (the stand-in limit is also referred to as the fallback level). A special pricing level can be used for each card.

If instant-on is allowed for a card type, set the Instant On field to Yes (N/A).

The Okay Flags field will display:

- 'E' if Expiration Date is enabled.
- 'F' if the card is accepted in Fallback mode.
- 'R' if Returns will be allowed.
- 'U' if unattended authorization is allowed. (You must run the command GASDIAL -g0 to activate.)
- 'V' if Voice Authorizations will be allowed.

Pay at the pump

Setting the *Island Preauth* amount field to \$1.00 for bank cards will cause the site to only dispense \$50 in fuel. You may override this \$50 limit but you must get approval from your network representative.

The host also returns an available-to-buy amount for fleet cards. This allows the host to maintain the maximum authorized amount for all terminals of a specific company.

Program New Cards for Acceptance (-O)

Gasboy Dial has the flexibility to have new cards added without a new version of the network software. The information for the card must be requested from your Network Representative and the Network must know you will be accepting the new card.

This menu allows the user to configure the Gasboy Dial software to accept a previously unknown card. This table must only be set up with the assistance of your Network Representative. Only 3 entries are available. Should these "Programmed" cards need to be made permanent, contact your Gasboy Sales Representative with a hard copy of the table for reference.

You will need your Network Representative to provide the following information before you can begin to edit the table:

- ISO account range (may also be referred to as the ABA Number)
- Track II account length as read from the stripe. This is the number of digits in the magnetically recorded account number before the expiration date, but not including the usual field separator found before the expiration date.
- Is merchandise accepted?

- · Purchasing limits
- Pay at the pump limits
- Do features like Fallback, Instant-On apply?
- Prompts required for authorization

A Name for the card type must be entered along with a 4 character Mnemonic name that will be printed on the receipt to help identify the card type should account disclosure restrictions at the island be enforced.


Select the programmed card entry you want to modify. If the card has only a single ABA number, then enter the same number for the ISO minimum and maximum. If an ISO account range is valid then enter the lower part of the ISO maximum column. The embossed length is the number of digits embossed on the card.


If the whole account is not embossed on the card, then usually the ABA number is added to the front of the card. This value is entered in the Manual Prefix. Several questions will be asked regarding cardholder prompts. If an auxiliary prompt is selected, you will need to enter the customer prompt message.

Cards with the name "Program 1", "Program 2", "Program 3", have not been programmed. Use the Edit Programmable Card Parameters (line item number 4) or type **GASDIAL -O**. The entry screens will be displayed as illustrated. You will be prompted for information that will help the site controller determine if the card swiped is acceptable. It also sets the limits of the sale. Program 1 is available in the first screen, Program 2 and 3 are available by pressing the RETURN key.

	Gas) Gasboy Inter Setup for CFN sboy(001) MMABLE CARD PA	/ 3		
CARD	SYM OK Okay Flags	Purch Isle Limit Auth			
1. Program 1	P1 Y E GMRUV	\$ 999 \$ 50	\$ 50 A	Credit	 N
	Acct Embossed Length Length		-		
	0 (0 0	0		
Aux Prompt Disp Enter Manual # Enter Item Number, W ?-Help, Q-Quit :		ETURN-Next Page	e,		


Selecting Program 1 will bring up the corresponding parameter editing screens as illustrated on the next page.







Edit Modem Parameters

Select option 5 from the Main Menu or type **GASDIAL -M** or **MODEMS** at the command line to setup your modem.



Selecting Item Number 1, *Modem Name* brings up the following 2 screens to select your type of modem.





After selecting the modem for the system, enter the correct baud rate and port usage for this system.

Change the baud setting by entering the number next to the baud rate shown at the bottom of the screen. For example, entering 2 will set the baud rate at 1200.

For port, enter the port number. For example, entering a 1 (one) will set the port to 1. For SCII, available ports are 1-3. For CFN3, available ports are 4-6.

Edit Instant-On for Pumps (-P) (not available)

If you do not want instant-on for some fuels, you can disable instant-on for the pumps that dispense those fuels. Select the appropriate pump and answer NO to the prompt.

Edit Product Cross References (-X)

This feature will allow you to map local product codes to an outside listing.

Select option 7 from the Main Menu or type GASDIAL -X at the command line to setup product cross references. The following 5 screens list the options.


		Copyright (2001) Gasboy International Network Setup for CFN/3									
		Gasboy(001)									
		EDIT PRODUCT CROSS REFERENCES									
	Local Local Host Host										
			Name								
		coue	Maille		-						
	1.	1	Diesel #2								
	2.	3	Premium	39	Other Fuel						
	Other Fuel										
	4.	5	Plus Nolead	39	Other Fuel						
	5.	б	Super Nolead	39	Other Fuel						
	6.	7	oil Qt.	39	Other Fuel						
	7.	8	Oil Gal.	39	Other Fuel						
	8.	10	C-STORE1	39	Other Fuel						
	9.	11	C-STORE2	39	Other Fuel						
	10.	12	C-STORE3	39	Other Fuel						
	Ente	r Item	Number, W-Walk	through,	RETURN-Next Page,						
	?-1	Help, Q	-Quit :								

	Local Code	Local Name	Host Code	Host Description
11. 12. 13. 14. 15. 16. 17. 18. 19. 20.	 13 14 15 16 17 18 19 20 21 22	Solvent Kerosene Propane Offrd Disct DSL Offroad Car Wash Regular SERVICES Cig. Pack Cig. Carton	39 39 39 39 39 39 39 39 39 39 39	Other Fuel Other Fuel Other Fuel Other Fuel Other Fuel Other Fuel Other Fuel Other Fuel Other Fuel Other Fuel

	Local Code	Local Name	Host Code	Host Description
21.	23	MOTOR OIL	39	Other Fuel
22.	24	CHIPS	39	Other Fuel
23.	25	CANDY	39	Other Fuel
24.	26	BEER/WINE	39	Other Fuel
25.	27	LOTTERY TKT	39	Other Fuel
26.	28	LOTTERY PAY	39	Other Fuel
27.	29	BOTTL RETURN	39	Other Fuel
28.	30	MISC. TAX	39	Other Fuel third page
29.	31	MISC. NONTAX	39	Other Fuel
30.	32	TOBACCO	39	Other Fuel


		Local Name	Code		
33. 34. 35. 36. 37. 38.	33 34 35 36 37 38 39 40 41	GROC. TAX GROC. NONTAX FOUNTAIN SODA SNACKS AUTO ACCESS	39 39 39 39 39 39 39 39 39	Other Fuel	fourth page
43. 44.	Code 44 45 46 47	DAIRY/JUICE Coffee	Code 39 39 39 39 39 39	Description Other Fuel Other Fuel Other Fuel Other Fuel Other Fuel	fifth page

For example: selecting Item Number 3, **4 Reg Nolead** from the first page brings up the following 4 screens to select the product cross reference.



	Host Code	Host Description
11.	11	Reformulated Unlead (86 or 87 octane)
12.	12	Con Unleaded
13.	13	Methanol Unleaded Regular (86 or 87 Octane) second page
14.	14	Reformulated Unleaded Plus
15.	15	Reformulated Super Unlead
16.	16	Ethanol Unleaded Premium (90-91)
17.	18	Propane
18.	19	CNG Gas
19.	20	Jet Fuel
20.	21	Methanol Unleaded Super (92 or 94 Octane)
-		

	Host Code	Host Description	
21. 22. 23. 24. 25. 26. 27. 28. 29. 30.	24 25 26 27 28 29	Methanol Unleaded Premium (90 or 91 Octane) Natural Gas Gasohol Gas - 10% Gasohol Gas - 7.7% Gasohol Gas - 5.7% White Gas Dual Propane/Unleaded	third page



Note: Quarles supports only a limited number of codes. These are:

- 03 Low Sulfur Diesel
- 06 High Sulfur Diesel
- 09 Unleaded Plus
- 10 Super Unleaded
- 14 Reformulated Unleaded Plus

11 Reformulated Unlead (86 or 87 octane)

15 Reformulated Super Unlead

12 Con Unleaded

Selecting any other option from the cross reference list will display an "Invalid product" message.


Print Current Gasboy Dial System Configuration (-S)


This option prints the complete configuration parameters. Five examples are illustrated.

Copyright (2001) Gasboy International Network Setup for CFN/3 Gasboy(001) SHOW NBS GROWMARK FLEET PARAMETERS	
 Main Bank Phone Number : 9,16123456789 Backup Bank Phone Number : 9,16123456789 Carrier Wait Timeout : 20 Verification Timeout : 45 Terminal Type : Merchant ID : GB1028112345678 Send Fleet Format to Host : Enabled Debit : Disabled Send Term Type to Host : NBS format Instant On : Disabled Instant On Timeout : 0 Fallback Sequence : 1 Press RETURN to continue. 	

13

		Сору	rig	ht (200			-				nal		
				Networ	k S	Setup) fo	or CF	'N/:	3			
				G	asl	ooy(O	01))					
		S	SHOW	I NBS GR	JWN	IARK I	FLE	et pa	RAM	ITERS			
													N/A
	CARD	SYM	OK	Okay	Ρı	ırch	Ιs	sle	Is	sle	Rcpt	Price	Inst
				Flags	L	imit	Aι	ıth	Ma	ax	Acct	Level	On
1.	VISA	VS	Y	EFRUV	\$	999	\$	1	\$	50	4	Credit	N
2.	MasterCard	MC	Y	EFRUV	\$	999	\$	1	\$	50	4	Credit	N
3.	Discover	DS	Y	EFRUV	\$	999	\$	1	\$	50	4	Credit	N
4.	AMEX	AX	Y	EFRUV	\$	999	\$	1	\$	50	4	Credit	N
5.	Gasboy Club	CLUB	Y	RUV	\$	999	\$	250	\$	250	A	3	N
б.	WEX	WX	Y	E RUV	\$	999	\$	250	\$	250	A	Credit	N
7.	PHH	PH	Y	E RUV	\$	999	\$	250	\$	250	S	Credit	N
8.	Voyager	VY	Y	E RUV	\$	999	\$	250	\$	250	A	Credit	N
9.	Fleet One	F1	Y	RUV	\$	999	\$	250	\$	250	A	Credit	N
10.	Visa Fleet	VSF	Y	E RUV	\$	999	\$	250	\$	250	A	Credit	N
Pre	ss RETURN to cont	tinue											






- Modem Name : Hayes Optima
 Baud Rate : 2400
 Port Number : 4
- Press RETURN to continue.

-										
		Cop	yright (2001) Gasboy International						
	Network Setup for CFN/3									
	Gasboy(001)									
	SHOW PRODUCT CROSS REFERENCES									
	Local	Local	Host	Host						
	Code	Name	Code	Description						
1.	1	Diesel #2	45	Diesel Plus						
2.	2. 3 Premium		02	Unleaded Premium Gas						
3.	4	Reg Nolead	01	Unleaded Gas						
4.	5	Plus Nolead	09	Unleaded Plus						
5.	6	Super Nolead	10	Super Unleaded						
6.	7	Oil Qt.	39	Other Fuel						
7.	8	Oil Gal.	39	Other Fuel						
8.	10	C-STORE1	39	Other Fuel						
9.	11	C-STORE2	39	Other Fuel						
10. 12 C-STORE3 39 Other Fuel										
Press RETURN to continue.										

Start Attended/Unattended Service (-G)


Attended or Unattended Service is available by selecting Menu Number 9 from the main menu or enter **GASDIAL** -**G**. Enter a 1 for Attended or 0 for Unattended service.



If using this command in a cron you must specify 1 or 0 in the command line. For an example, see *Disabling cards at the Island during the evening* on page 13.

Remove Transactions from Batch (-D)

If you are encountering network errors with a transaction, that transaction can be deleted from the next settlement attempt. You need its transaction number (this should be stored in the log or check PRint TRansactions) to delete it. You will need to consult with your network representative about the deletion. If this option is selected you will be prompted to enter the transaction number.



Read/Write Network Parameters from/to file (-R/-W)

Use these screens to copy or write existing parameters to/from a file.



Detailed notes on system setup

Tables (TABLE)

- The receipt table must have at least 100 entries.
- Router table should have 1808 or above entries. Must be an even number.
- Auth table should have 75 entries.

Note: Router table cannot be set to odd numbers.

Transaction format (TRFMT)

Make certain that the transaction printout format includes the authorization number (field type 3) and dollar amount (field type 11).

System Date

Make sure the system date and time is correct. PRint DAte will display the date and time. LOad DAte will allow you to change it.

17

Disabling Cards at the Island during the evening

To disable taking cards at the Island, you can load a cron which then runs: GASDIAL -g0 (zero)

Another cron can be used to enable the cards at the Island. Set the cron to run: GASDIAL -g1 (one)

System Parameters (SYS_PAR)

This information is provided for reference. The menu programs initialize and/or store the appropriate values for you in the system parameters.

Club Card (Growmark Fuel24 setup only)

Digits in system ID: 4 Digits in account #: 13 Digits in allocation: 3 Digits in vehicle #.: 3 Digits in expiration date: 0 Digits in limitation code: 1 Digits in authorization code: 1 Digits in price level: 1 Digits in restriction code: 1 Digits used in PIN calculation: 13 Digits in checking PIN: 4 Digits in savings PIN: 4 Digits in credit PIN: 4

Club card format - offsets (Growmark Fuel24 setup only)

Allocation account offset: Vehicle account offset: Limitation code offset: Authorization code offset: Price level offset: Restriction code offset: PIN calculation offset: Extra card digit offset: CLUB bit-mapped account offset:

Reader verification

Use remote verification (reader): **credit checking savings [club]** Use local verification (reader): **club (Growmark Fuel24)** Require PIN (reader): **club (Growmark Fuel24)** Check mod 10 (reader): **none** Check expiration date (reader): **none** Lockout on remote verification: **none** Reader default payment is: **credit**

Console verification

Use remote verification (console): **credit checking savings [club]** Use local verification (console): **club (Growmark Fuel24)** Require PIN (console): **club (Growmark Fuel24)** Check mod 10 (console): **none** Check expiration date (console): **none** Lockout on remote verification: **none**

Other Parameters

Verification

Verification timeout (Routers): **60** set in Network parameters. This should be a minimum of 45, but can also be set to 0 for no timeout.

Receipt

Print manual # on receipt: Yes Text used on receipt for manual number: Manual

Console (CONSOLE)

After running initialization, these parameters are set to these values: Auxiliary Number prompt: **Enter vehicle #** Allow hand entry of card data: **Yes** POS asks for odometer on fuel sale: **1 (Card-encoded)** POS asks for auxiliary # on fuel sale: **1 (Card-encoded)** POS asks for odometer on merchandise sale: **1 (Card-encoded)** POS asks for auxiliary # on merchandise sale: **1 (Card-encoded)**

Reader (READER)

Below is an example of the reader program settings that will work for Gasboy Dial Generic:

	#	Ty 1	S/I		DISPLAY < < Slide Card < <	WHILE ENTERING	OPTIONS
	2	3	6 6	!	PIN ? Hub/Odo ?	!Your PIN !Hub/Odo	! Optional Masked ! Optional
	4	6	8	!	Vehicle #	!Vehicle #	! Optional
	5 6	2 8		!	Select pump Please Wait	!Pump !	! Auto-enter !
	·	13 14			#XX Ok for \$0000.00	! !	! !
1	9 0	9		! !	END	! - !	! !

For Debit you will need the Select Account step as the second program step (not available).

#	Ty S	/D	DISPLAY	WHILE ENTERING	OPTIONS
1	1		! < < Slide Card < <	!	!
2	4	8	! \$ Amount or FILL	!\$ Amount	!
3	3	б	! PIN ?	!Your PIN	! Optional Masked
4	7	б	! Hub/Odo ?	!Hub/Odo	! Optional
5	б	8	! Vehicle #	!Vehicle #	! Optional
6	8		! Please Wait	!	!
7	13	0	!P#XX	!	!
8	14	2	!^ Ok for \$0000.00	!	!
9	9		1	1	!
10			!END	- !	!

Settlement for Gasboy Dial

When the SETTLE command is used, an end-of-settlement signal will be sent to the host. A more complete settlement process will be implemented in a future version.

If you want the SETTLE command to work with the end-of-day report, you will need to edit the nextday.cmd file.

Error messages

Host rejected completion, #nn,'reason'

Infrequently, the network may initially authorize the use of a card, but when the transaction is completed, reject the completion of that transaction. In this unlikely event, you will see this message.

This indicates that a preauthorized sale, transaction nn, cannot be completed. The error code x/yy will explain why. The transaction is marked with the authorization code, REJCMP.

If you repeatedly encounter this error, contact Gasboy technical services. If this situation occurs, make a record of the error message, and contact your Gasboy Service Representative to find out what to do next. You may run **GASBOY** -**D** # to remove the transaction from the completion list.

Network Halted

You must initialize the network software.

Bad Fleet data format request Bad fleet completion format request

Contact your GASBOY representative should you ever see this message.

Adjust Tables, Router Table min=xxxx

Run TABLES and allow for the specified number of bytes for the Router Table.

Fleet Format Disabled

System is not programmed for fleet applications. run **GASDIAL** -**E** and enable the "Fleet Format" field.

Unknown Card Type (not available)

If a debit card is used, the Debit key must be pressed. Otherwise, the card is not programmed to be accepted.

Special console operations

Special credit card keys for manual entry

With some cards you will need to set up a special key on the console for handling the manual entry of credit cards. The manual-entry process is identical to the standard method of using the CREDIT key (which is described in the *Check Point* and *Profit Point* manuals). Once you make the assignment with the directions below, the key should be labeled to indicate its new use.

Check Point consoles

Submenu 1 of the CONSOLE configuration program (explained in the *Site Controller II Configuration Manual*) is used to assign a card type to a Check Point key. Assign action 85 to a key to manually accept the cards on that key.

Profit Point consoles

On the Profit Point, special function 68 calls up the network-card-selection menu. You can deactivate the networks you don't want by commenting out the appropriate line in the CONFIG.POS file with an asterisk in the first column.

If your CONFIG.POS file has a line that reads NETWORK TEXACO CARD=95, either change TEXACO to PHILLIPS, or comment out that line and add one that reads NETWORK xxxxxx CARD=95.

The transaction pointer

If you are not regularly polling and resetting the transaction pointer, then you should run the PURGE SITE command once a day so you do not fill up the Site Controller's memory.

Troubleshooting

Version 2.3 Site Controller software

If your site is having problems with dial-out host connections, type this command at the prompt:

C: debug 2 2

This will start the debug program that will write the important occurrences to the log file. Let this run until the problem occurs. Once the problem has been logged, type:

C: debug 0

to turn the debugger off.

NOTE: Turn debug off when completed or a large router.log file will be created. This will slow your system down, making it difficult to function properly.

If your site is not dialing after credit card authorizations are attempted, check that:

- 1. The correct phone number is entered.
- 2. Lockout on Remote Verification parameter (SYS_PAR) for the reader and/or console is set to CREDIT and Page 8 has CREDIT for "send request to host".
- 3. The card is enabled for use with this site (GASDIAL -C command).
- 4. You are not getting warnings related to the router table size.
- 5. Run PR DI 1. Check that it doesn't report "No bank verification".
- 6. You have run the **MODEMS** program and have selected the correct modem type.

If, in the file, you see many occurrences of:

>>Modem init. error

Run MODEMS, check the modem selected or try a different configuration. If your modem is not in the list, try each of the selections 1-5. If it still fails, your modem may not be Hayes compatible. The program shows a list of GASBOY certified modems.

>>Busy

You may have the wrong phone number entered.

>> No dialtone

Check your modem's phone line.

>> Lost Carrier

- 1. Increase the carrier detect timeout in the network parameters
- 2. Have your phone line checked.

22